


CHAIN TERMINAL

SRB series (With insulation grip) <Made in Belgium>



UL LISTED file No. E42024 DIN 46225 (except *-marked items)

Model No.	Standard	Applicable wire			Material	Finish	Dimensions(mm)					Q'ty / reel									
		mm ²	AWG #	Insulation O.D. (mm)			W	L	E	d (dia.)	Material thickness										
SRB-1.0-M3	UL LISTED	0.5 to 1.0	20 to 18	2.0 to 3.3	Brass	—	8.0	21.0	17.0	3.2	0.6	5,000									
SRB-1.0T-M3						Tin-plated															
SRB-1.0-M3-W9.5 *						—															
SRB-1.0T-M3-W9.5 *						Tin-plated															
SRB-2.5-M3	UL LISTED	1.0 to 2.5	18 to 14	2.7 to 4.3	Brass	—	8.0	21.0				17.0	3.2	0.6	4,000						
SRB-2.5T-M3						Tin-plated															
SRB-2.5-M3-W9.5 *						—															
SRB-2.5T-M3-W9.5 *						Tin-plated															
SRB-1.0-M4	UL LISTED	0.5 to 1.0	20 to 18	2.0 to 3.3	Brass	—	8.0	21.0							17.0	4.3	0.6	5,000			
SRB-1.0T-M4						Tin-plated															
SRB-1.0-M4-W9.5 *						—															
SRB-1.0T-M4-W9.5 *						Tin-plated															
SRB-2.5-M4	UL LISTED	1.0 to 2.5	18 to 14	2.7 to 4.3	Brass	—	8.0	21.0	17.0	4.3	0.6							4,000			
SRB-2.5T-M4						Tin-plated															
SRB-2.5-M4-W9.5 *						—															
SRB-2.5T-M4-W9.5 *						Tin-plated															
SRB-1.0-M5-W8	UL LISTED	0.5 to 1.0	20 to 18	2.0 to 3.3	Brass	—	8.0	21.0				17.0	5.3	0.6				5,000			
SRB-1.0T-M5-W8 *						Tin-plated															
SRB-1.0-M5						—															
SRB-1.0T-M5						Tin-plated															
SRB-2.5-M5-W8 *	UL LISTED	1.0 to 2.5	18 to 14	2.7 to 4.3	Brass	—	8.0	21.0							17.0	5.3	0.6	4,000			
SRB-2.5T-M5-W8 *						Tin-plated															
SRB-2.5-M5						—															
SRB-2.5T-M5						Tin-plated															
SRB-1.0-M6 *	UL LISTED	0.5 to 1.0	20 to 18	2.0 to 3.3	Brass	—	9.5	21.75	17.0	6.5	0.6							4,000			
SRB-1.0T-M6 *						Tin-plated															
SRB-2.5-M6 *	UL LISTED	1.0 to 2.5	18 to 14	2.7 to 4.3	Brass	—	9.5	21.75										17.0	6.5	0.6	4,000
SRB-2.5T-M6 *						Tin-plated															

RoHS compliance

- * RoHS compliant products are published.
- * Refer to "General Instruction and Notice when using Terminals and Connectors" at the end of this catalog.
- * Contact JST for details.